


KinderSign – Power Management of your Tablet

At the end of the business day, power off your device and charge the tablet using a wall outlet. In the morning, unplug the tablet and power it back on. It is very important to charge the battery properly and safely. We recommend that:

- To charge your tablet, use only the supplied Samsung USB/charging cables and avoid third-party accessories.
- Ensure the USB/charging cable is connected securely and is not being blocked by your tablet cover or case.
- Make sure the battery or charging indicator  appears on the tablet's display when the USB/charging cable is connected.
- Use the outlet on your wall instead of your computer.
- Disconnect the tablet from the USB/charging cable after the battery is fully charged.
- Do not keep the tablet plugged in all day since it will reduce the life of the battery.